


**ROOF PANEL FASTENER SPACING**

**NOTE:**  
 Screw installation - Tyler Building Systems' standard roof, wall, and trim screws are self-drilling and should be installed using a screw gun turning at a maximum of 2,000 RPM, Series 300 stainless steel screws are not self-drilling screws. Panels and secondary structural material must be pre-drilled before installing the screws. Series 300 stainless steel screws should be installed with a screw gun turning at 800 RPM. Using a screw gun turning faster than 800 RPM will damage the screws.

 P.O. BOX 130819 • TYLER, TEXAS 75713	<b>ERECTION STANDARDS</b>	DRAWING
	<b>ROOF PANEL FASTENER SPACING</b>	<b>ES-163</b>