



FASTENER SPACING AT RAKE, EAVE AND BASE




INTERMEDIATE FASTENER SPACING



SIDLAP DETAIL

WALL PANEL FASTENER SPACING

NOTE:
 Screw installation - Tyler Building Systems' standard roof, wall, and trim screws are self-drilling and should be installed using a screw gun turning at a maximum of 2,000 RPM, Series 300 stainless steel screws are not self-drilling screws. Panels and secondary structural material must be pre-drilled before installing the screws. Series 300 stainless steel screws should be installed with a screw gun turning at 800 RPM. Using a screw gun turning faster than 800 RPM will damage the screws.

| | | |
|--|-----------------------------|--------------------------|
|  <p>TYLER BUILDING SYSTEMS, L.P. P.O. BOX 130819 • TYLER, TEXAS 75713</p> | ERECTION STANDARDS | DRAWING ES-161 |
| | WALL PANEL FASTENER SPACING | |